

Economize na quantidade de anticorpo nas incubações de WB e tenha melhores resultados

Incube nos sacos Hybri-bag

Hybri-Bag

High Strength (Soft: 0~+80°C, Hard: 0~+120°C) Composite Film - Easy to seal with a Heat Sealer - No Non-specific Binding (Non Powder product) - Clear and Smooth surface - Reasonable Price



1. Cut the Hybri-bag to adjust the size to the membrane.
2. Put membrane and buffer including antibody into the Hybri-bag, and seal with a heat sealer. (Note that you need to remove the bubbles from the hybri-bag when you seal to perform even blocking.)
3. Perform blocking on the shaker.

